

THANKS FOR WATCHING

Your feedback is invaluable to us and we would love to hear about your experience. Please take the time to leave us a review. HT60100 / HT60101 / HT60102 HT80100 / HT80101 / HT80102 HT10100 / HT10101 / HT10102










Thank you for shopping with us!

We encourage you to take a few minutes to go through this booklet. It contains important information on installation and care tips to keep your furniture looking as good as new.







CARE CLEANING AND MAINTENANCE

- 1.Dust regularly with a soft, dry cloth.
- 2.Avoid the use of all chemicals household cleaners, abrasives, or cleaners that contain lemon, vinegar, or other acids that may damage the finish.
- 3.Excessive exposure to sunlight and extreme changes in temperature and moisture can damage wood furniture.
- 4. The sink top is resilient, but care needs to be taken to preserve its appearance.
- 5.Do not place hot appliances, such as curling irons and hot hair dryers directly on the countertop. Wipe spills immediately.

a	Left	t 2x	1	Left 1x
b	Rig	ht 2x	2	Right 1 x
C	M7*40mm	6x	3	1x
d	Ф14	66x	4	1x
е		66x	5	1x
f	50mm	6x	6	1x
g	40mm	1x	7	1x
h	anga O	6x	8	2x
j	14mm	30x	9	Top 1x
k		2x	10	Bottom 1 x
u		1x	11	\sum Left $2x$
			12	$\sqrt{\sum}$ Right $2x$
			13	\sum_{x}
			14	\Box 1x
			15	\Box 1x
			14 15	

